

STAFFE

STAFFE
BRACKETS
HALTESTÜCKE
BRIDAS




Staffe standard per bussole e colonne estraibili.

Standard brackets for bushing and extractable columns.

Haltestücke für Buchsen und ausbaubare Säulen.

Bridas standard para casquillos y columnas extraíbles.

STAFFE
BRACKETS
HALTESTÜCKE
BRIDAS



| Codice - Code Kode - Código | B h9 | L ₀ ⁰ _{0.4} | H h11 | B1 | D1 ₀ ^{+0.2} | D2 ₀ ^{+0.2} | T1 _{-0.3} ⁰ | T2 _{-0.3} ⁰ | T3 ₀ ^{+0.3} |
|--------------------------------|------|--|-------|-----|---------------------------------|---------------------------------|---------------------------------|---------------------------------|---------------------------------|
| S20.20.6 | 20 | 20 | 10 | 7.5 | 6.5 | 11 | 7 | 6.3 | 5 |
| S25.20.6 | 25 | 20 | 12 | 10 | 9 | 15 | 8.5 | 6.3 | 5 |
| S32.25.6 | 32 | 25 | 16 | 11 | 11 | 18 | 11 | 6.3 | 10 |
| S32.32.10 | 32 | 32 | 16 | 11 | 11 | 18 | 11 | 10 | 10 |
| S32.32.6 | 32 | 32 | 16 | 11 | 11 | 18 | 11 | 6.3 | 10 |